

NexCOBOT Co., Ltd.

IoT Automation Solutions Business Group

Industrial Robot Controller

RCB 100

User Manual

CONTENTS

Preface

Copyright	iv
Disclaimer	iv
Acknowledgements	iv
Regulatory Compliance Statements	iv
Declaration of Conformity	iv
RoHS Compliance	v
Warranty and RMA	vi
Safety Information	viii
Installation Recommendations	viii
Safety Precautions	ix
Technical Support and Assistance	x
Conventions Used in this Manual	x
Global Service Contact Information	xi
Package Contents	xii
Ordering Information	xiii

Chapter 1: Product Introduction

Overview	1
Key Features	1
Hardware Specifications	2
Knowing Your RCB 100	3
Top View	3
I/O Interfaces	4

Chapter 2: Jumpers and Connectors

Before You Begin	5
Precautions	5
Jumper Settings	6
Locations of the Jumpers and Connectors	7
Jumpers	8
AT/ATX Power Type Selection	8
RTC Clear	8
Connector Pin Definitions	9
External I/O Interfaces	9
COM Port	9
HDMI	9
LAN and USB 3.0 Ports	10
USB 2.0 Ports	11
LAN2 Port (PoE function requires optional PSE module)	11
Internal Connectors	12
DC-in Connector	12
Power Connector	12
Reset Connector	13
BIOS Programming (for debugging only)	13
PoE Connector	14
Internal LAN3 Port	14
Internal LAN4 Port	15
Internal USB 2.0 Connector	15
Internal USB 2.0 Connector	16
SATA Connector	16



SATA Power Connector	17
RS232/RS422/RS485 Serial Port Box Header	17
RTC Battery Connector.....	18
System Fan Connector	18
CPU Fan Connector.....	19
VGA Connector	19
GPIO Connector.....	20
Mini-PCIe Connector.....	21
PCIe x16 Slot.....	22
Block Diagram	24

Chapter 3: BIOS Setup

About BIOS Setup	25
When to Configure the BIOS.....	25
Default Configuration	26
Entering Setup	26
Legends	26
BIOS Setup Utility.....	28
Main	28
Advanced	29
Chipset.....	35
Security	38
Boot	39
Save & Exit	40

PREFACE

Copyright

This publication, including all photographs, illustrations and software, is protected under international copyright laws, with all rights reserved. No part of this manual may be reproduced, copied, translated or transmitted in any form or by any means without the prior written consent from Nexcobot Co., Ltd.

Disclaimer

The information in this document is subject to change without prior notice and does not represent commitment from Nexcobot Co., Ltd. However, users may update their knowledge of any product in use by constantly checking its manual posted on our website: <http://www.nexcobot.com>. NexCOBOT shall not be liable for direct, indirect, special, incidental, or consequential damages arising out of the use of any product, nor for any infringements upon the rights of third parties, which may result from such use. Any implied warranties of merchantability or fitness for any particular purpose is also disclaimed.

Acknowledgements

RCB 100 is a trademark of Nexcobot Co., Ltd. All other product names mentioned herein are registered trademarks of their respective owners.

Regulatory Compliance Statements

This section provides the FCC compliance statement for Class A devices and describes how to keep the system CE compliant.

Declaration of Conformity

FCC

This equipment has been tested and verified to comply with the limits for a Class A digital device, pursuant to Part 15 of FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. Operation of this equipment in a residential area (domestic environment) is likely to cause harmful interference, in which case the user will be required to correct the interference (take adequate measures) at their own expense.

CE

The product(s) described in this manual complies with all applicable European Union (CE) directives if it has a CE marking. For computer systems to remain CE compliant, only CE-compliant parts may be used. Maintaining CE compliance also requires proper cable and cabling techniques.

RoHS Compliance



NexCOBOT RoHS Environmental Policy and Status Update

NexCOBOT is a global citizen for building the digital infrastructure. We are committed to providing green products and services, which are compliant with European Union RoHS (Restriction on Use of Hazardous Substance in Electronic Equipment) directive 2011/65/EU, to be your trusted green partner and to protect our environment.

RoHS restricts the use of Lead (Pb) < 0.1% or 1,000ppm, Mercury (Hg) < 0.1% or 1,000ppm, Cadmium (Cd) < 0.01% or 100ppm, Hexavalent Chromium (Cr6+) < 0.1% or 1,000ppm, Polybrominated biphenyls (PBB) < 0.1% or 1,000ppm, and Polybrominated diphenyl Ethers (PBDE) < 0.1% or 1,000ppm.

In order to meet the RoHS compliant directives, NexCOBOT has established an engineering and manufacturing task force in to implement the introduction of green products. The task force will ensure that we follow the standard NexCOBOT development procedure and that all the new RoHS components and new manufacturing processes maintain the highest industry quality levels for which NexCOBOT are renowned.

The model selection criteria will be based on market demand. Vendors and suppliers will ensure that all designed components will be RoHS compliant.

How to recognize NexCOBOT RoHS Products?

For existing products where there are non-RoHS and RoHS versions, the suffix "(LF)" will be added to the compliant product name.

All new product models launched after January 2013 will be RoHS compliant. They will use the usual NexCOBOT naming convention.

Warranty and RMA

NexCOBOT Warranty Period

NexCOBOT manufactures products that are new or equivalent to new in accordance with industry standard. NexCOBOT warrants that products will be free from defect in material and workmanship for 2 years, beginning on the date of invoice by NexCOBOT.

NexCOBOT Return Merchandise Authorization (RMA)

- Customers shall enclose the “NexCOBOT RMA Service Form” with the returned packages.
- Customers must collect all the information about the problems encountered and note anything abnormal or, print out any on-screen messages, and describe the problems on the “NexCOBOT RMA Service Form” for the RMA number apply process.
- Customers can send back the faulty products with or without accessories (manuals, cable, etc.) and any components from the card, such as CPU and RAM. If the components were suspected as part of the problems, please note clearly which components are included. Otherwise, NexCOBOT is not responsible for the devices/parts.
- Customers are responsible for the safe packaging of defective products, making sure it is durable enough to be resistant against further damage and deterioration during transportation. In case of damages occurred during transportation, the repair is treated as “Out of Warranty.”
- Any products returned by NexCOBOT to other locations besides the customers’ site will bear an extra charge and will be billed to the customer.

Repair Service Charges for Out-of-Warranty Products

NexCOBOT will charge for out-of-warranty products in two categories, one is basic diagnostic fee and another is component (product) fee.

System Level

- Component fee: NexCOBOT will only charge for main components such as SMD chip, BGA chip, etc. Passive components will be repaired for free, ex: resistor, capacitor.
- Items will be replaced with NexCOBOT products if the original one cannot be repaired. Ex: motherboard, power supply, etc.
- Replace with 3rd party products if needed.
- If RMA goods can not be repaired, NexCOBOT will return it to the customer without any charge.

Board Level

- Component fee: NexCOBOT will only charge for main components, such as SMD chip, BGA chip, etc. Passive components will be repaired for free, ex: resistors, capacitors.
- If RMA goods can not be repaired, NexCOBOT will return it to the customer without any charge.



Warnings

Read and adhere to all warnings, cautions, and notices in this guide and the documentation supplied with the chassis, power supply, and accessory modules. If the instructions for the chassis and power supply are inconsistent with these instructions or the instructions for accessory modules, contact the supplier to find out how you can ensure that your computer meets safety and regulatory requirements.

Cautions

Electrostatic discharge (ESD) can damage system components. Do the described procedures only at an ESD workstation. If no such station is available, you can provide some ESD protection by wearing an antistatic wrist strap and attaching it to a metal part of the computer chassis.

Safety Information

Before installing and using the device, note the following precautions:

- Read all instructions carefully.
- Do not place the unit on an unstable surface, cart, or stand.
- Follow all warnings and cautions in this manual.
- When replacing parts, ensure that your service technician uses parts specified by the manufacturer.
- Avoid using the system near water, in direct sunlight, or near a heating device.
- The load of the system unit does not solely rely for support from the rackmounts located on the sides. Firm support from the bottom is highly necessary in order to provide balance stability.
- The computer is provided with a battery-powered real-time clock circuit. There is a danger of explosion if battery is incorrectly replaced. Replace only with the same or equivalent type recommended by the manufacturer. Discard used batteries according to the manufacturer's instructions.

Installation Recommendations

Ensure you have a stable, clean working environment. Dust and dirt can get into components and cause a malfunction. Use containers to keep small components separated.

Adequate lighting and proper tools can prevent you from accidentally damaging the internal components. Most of the procedures that follow require only a few simple tools, including the following:

- A Philips screwdriver
- A flat-tipped screwdriver
- A grounding strap
- An anti-static pad

Using your fingers can disconnect most of the connections. It is recommended that you do not use needle-nose pliers to disconnect connections as these can damage the soft metal or plastic parts of the connectors.

Safety Precautions

1. Read these safety instructions carefully.
2. Keep this User Manual for later reference.
3. Disconnect the equipment from any AC outlet before cleaning or installing a component inside the chassis. Use a damp cloth. Do not use liquid or spray detergents for cleaning.
4. To prevent electrostatic build-up, leave the board in its anti-static bag until you are ready to install it.
5. For plug-in equipment, the power outlet socket must be located near the equipment and must be easily accessible.
6. Keep the board away from humidity.
7. Put the board on a stable surface. Dropping it or letting it fall may cause damage.
8. Wear anti-static wrist strap.
9. Do all preparation work on a static-free surface.
10. Make sure the voltage of the power source is correct before connecting the equipment to the power outlet.
11. Hold the board only by its edges. Be careful not to touch any of the components, contacts or connections.
12. All cautions and warnings on the board should be noted.
13. Use the correct mounting screws and do not over tighten the screws.
14. Keep the original packaging and the anti-static bag; in case the board has to be returned for repair or replacement.

Technical Support and Assistance

1. For the most updated information of NexCOBOT products, visit NexCOBOT's website at www.nexcobot.com.
2. For technical issues that require contacting our technical support team or sales representative, please have the following information ready before calling:
 - Product name and serial number
 - Detailed information of the peripheral devices
 - Detailed information of the installed software (operating system, version, application software, etc.)
 - A complete description of the problem
 - The exact wordings of the error messages

Warning!

1. Handling the unit: carry the unit with both hands and handle it with care.
2. Maintenance: to keep the unit clean, use only approved cleaning products or clean with a dry cloth.

Conventions Used in this Manual



Warning:

Information about certain situations, which if not observed, can cause personal injury. This will prevent injury to yourself when performing a task.



Caution:

Information to avoid damaging components or losing data.



Note:

Provides additional information to complete a task easily.

Global Service Contact Information

Asia

Taiwan

NexCOBOT Taiwan

13F, No.916, Chung-Cheng Rd.,
ZhongHe District,
New Taipei City, 23586, Taiwan, R.O.C.
Tel: +886-2-8226-7796
Fax: +886-2-8226-7792
Email: sales@nexcobot.com
www.nexcobot.com.tw

China

NexCOBOT China

Room 501, Building 1, Haichuang Building,
No.7 Qingyi Rd., Guicheng Street,
Nanhai District, Foshan City,
Guangdong Province, 528314, China
Tel: +86-757-8625-7118
Email: sales@nexcobot.com
www.nexcobot.com.cn

America

USA

NexCOBOT USA

2883 Bayview Drive,
Fremont CA 94538, USA
Tel: +1-510-362-0800
Email: sales@nexcobot.com
www.nexcobot.com.cn

Package Contents

Before continuing, verify that the RCB 100 package that you received is complete. Your package should have all the items listed in the following table.

Item	Name	Qty
1	RCB 100 Mainboard	1
2	Driver CD	1
3	Quick Guide	1

Optional Accessories

Item	Part Number	Name	Description
1	10J200RCB04X0	NISKPoE Kit for RCB 100 (A001)	PoE PSE Module



Ordering Information

The following below provides ordering information for RCB 100.

RCB 100 (P/N: 10J200RCB00X0)

Mini-ITX board, 6th generation Intel® Core™ i7/i5/i3 and Intel® Celeron® processor support


NISKPoE Kit (P/N: 10J200RCB04X0)

PoE PSE Module



CHAPTER 1: PRODUCT INTRODUCTION

Overview



Key Features

- Mini-ITX form factor
- 6th generation Intel® Core™ i7/i5/i3 and Intel® Celeron® processors
- Internal USB for software license dongle
- Optional digital isolated I/O
- PoE for machine vision application
- Internal VGA for teach pendant

Hardware Specifications

CPU Support

- Socket LGA1151, 6th generation Intel® Core™ i7/i5/i3 processors and Intel® Celeron® processors, 14nm process

Main Memory

- Dual DDR4/SO-DIMMs, up to 32GB

Chipset

- Intel® H110 PCH

Onboard Interface

- 2 x I210-AT GbE LAN
- 2 x USB 2.0
- 1 x VGA (1920 x 1200 @ 60Hz)
- 1 x RS232/422/485 with auto flow control
- 12in (NPN/PNP type), 4out (NPN type); requires optional board

Display

- 1 x HDMI (4096 x 2160 @ 24Hz, 24 bpp)

Expansion

- 1 x PCIe x16 Gen3
- 1 x Mini-PCIe
- 1 x SATA

Edge I/O Interface

- 1 x RS232/422/485 with auto flow control (default RI)
- 2 x USB 3.0, 4 x USB 2.0
- 2 x I211AT GbE LAN (one port can be used as a PoE port, IEEE 802.3af compliant; requires optional PSE board)

Audio

- Not supported

Power Input

- Support AT/ATX mode
- ATX 4-pin connector for 24V \pm 10%

Form Factor

- Dimensions: Mini-ITX (6.7-in x 6.7-in)

Environment


- Operating temperatures: 0°C to 60°C with CPU fan and system fan
- Storage temperature: -20°C to 80°C
- Relative humidity: 90%

Certifications


- CE
- FCC Class A
- EN61000-6-4 / EN61000-6-2

Knowing Your RCB 100

Top View



I/O Interfaces



CHAPTER 2: JUMPERS AND CONNECTORS

This chapter describes how to set the jumpers and connectors on the RCB 100 motherboard.

Before You Begin

- Ensure you have a stable, clean working environment. Dust and dirt can get into components and cause a malfunction. Use containers to keep small components separated.
- Adequate lighting and proper tools can prevent you from accidentally damaging the internal components. Most of the procedures that follow require only a few simple tools, including the following:
 - A Philips screwdriver
 - A flat-tipped screwdriver
 - A set of jewelers screwdrivers
 - A grounding strap
 - An anti-static pad
- Using your fingers can disconnect most of the connections. It is recommended that you do not use needle-nosed pliers to disconnect connections as these can damage the soft metal or plastic parts of the connectors.
- Before working on internal components, make sure that the power is off. Ground yourself before touching any internal components, by touching a metal object. Static electricity can damage many of the electronic components. Humid environments tend to have less static electricity than

dry environments. A grounding strap is warranted whenever danger of static electricity exists.

Precautions

Computer components and electronic circuit boards can be damaged by discharges of static electricity. Working on computers that are still connected to a power supply can be extremely dangerous.

Follow the guidelines below to avoid damage to your computer or yourself:


- Always disconnect the unit from the power outlet whenever you are working inside the case.
- If possible, wear a grounded wrist strap when you are working inside the computer case. Alternatively, discharge any static electricity by touching the bare metal chassis of the unit case, or the bare metal body of any other grounded appliance.
- Hold electronic circuit boards by the edges only. Do not touch the components on the board unless it is necessary to do so. Don't flex or stress the circuit board.
- Leave all components inside the static-proof packaging that they shipped with until they are ready for installation.
- Use correct screws and do not over tighten screws.

Jumper Settings


A jumper is the simplest kind of electric switch. It consists of two metal pins and a cap. When setting the jumpers, ensure that the jumper caps are placed on the correct pins. When the jumper cap is placed on both pins, the jumper is short. If you remove the jumper cap, or place the jumper cap on just one pin, the jumper is open.

Refer to the illustrations below for examples of what the 2-pin and 3-pin jumpers look like when they are short (on) and open (off).

Two-Pin Jumpers: Open (Left) and Short (Right)




Three-Pin Jumpers: Pins 1 and 2 are Short



Locations of the Jumpers and Connectors

The figure below shows the location of the jumpers and connectors.



Jumpers

AT/ATX Power Type Selection

Connector type: 1x3 3-pin header, 2.0mm pitch
Connector location: JATX1



Pin	Function
1-2 On	ATX Mode
2-3 On	AT Mode

2-3 On: default

Pin	Definition
1	Manual (ATX MODE)
2	PWRBT In
3	AUTO (AT MODE)

RTC Clear

Connector type: 1x3 3-pin header, 2.54mm pitch
Connector location: JRTC1



Pin	Definition
1	VCCRTC
2	VCCRTC_R
3	GND

1-2 On: default


Connector Pin Definitions

External I/O Interfaces

COM Port

Connector type: DB-9 port, 9-pin D-Sub

Connector location: COM1




Pin	Definition	Pin	Definition
1	COM_DCD#1	2	COM_RXD#1
3	COM_TXD#1	4	COM_DTR#1
5	COM_GND	6	COM_DSR#1
7	COM_RTS#1	8	COM_CTS#1
9	COM_RI#1		

HDMI

Connector type: HDMI port

Connector location: HDMI1




Pin	Definition	Pin	Definition
1	HDMI_D2+_C	2	GND
3	HDMI_D2-_C	4	HDMI_D1+_C
5	GND	6	HDMI_D1-_C
7	HDMI_D0+_C	8	GND
9	HDMI_D0-_C	10	HDMI_CK+_C
11	GND	12	HDMI_CK-_C
13	NC	14	NC
15	HDMI_SCL_C	16	HDMI_SDA_C
17	GND	18	VCC5
19	HDMI_HPD		

LAN and USB 3.0 Ports

Connector type: RJ45 port with LEDs

Dual USB 3.0 ports, Type A

Connector location: CON1



Act	Status
Flashing Yellow	Data activity
Off	No activity

Link	Status
Steady Green	1G network link
Steady Orange	100Mbps network link
Off	10Mbps or no link


Pin	Definition	Pin	Definition
1	P5V_USB_P01	2	USB2N1_C
3	USB2P1_C	4	GND
5	USB3RN1_C	6	USB3RP1_C
7	GND	8	USB3TN1_C
9	USB3TP1_C	10	P5V_USB_P01
11	USB2N2_C	12	USB2P2_C
13	GND	14	USB3RN2_C
15	USB3RP2_C	16	GND

Pin	Definition	Pin	Definition
17	USB3TN2_C	18	USB3TP2_C
19	LAN1_VCC	20	LAN1_MDI0P
21	LAN1_MDI0N	22	LAN1_MDI1P
23	LAN1_MDI1N	24	LAN1_MDI2P
25	LAN1_MDI2N	26	LAN1_MDI3P
27	LAN1_MDI3N	28	GND
29	LAN1_ACT_P	30	ACT_LED#
31	LAN1_LINK100#_P	32	LAN1_LINK1G#

USB 2.0 Ports

Connector type: Four USB 2.0 ports, Type A

Connector location: CN2




Pin	Definition	Pin	Definition
1	P5V_USB_P56	2	USB2N5_C
3	USB2P5_C	4	GND
5	P5V_USB_P56	6	USB2N6_C
7	USB2P6_C	8	GND
9	P5V_USB_P78	10	USB2N7_C
11	USB2P7_C	12	GND
13	P5V_USB_P78	14	USB2N8_C
15	USB2P8_C	16	GND

LAN2 Port (PoE function requires optional PSE module)

Connector type: RJ45 port with LEDs

Connector location: LAN2



Act	Status
Flashing Yellow	Data activity
Off	No activity


Link	Status
Steady Green	1G network link
Steady Orange	100Mbps network link
Off	10Mbps or no link

Pin	Definition	Pin	Definition
1	NC	2	LAN2_MDI2N
3	LAN2_MDI2P	4	LAN2_MDI1P
5	LAN2_MDI1N	6	NC
7	NC	8	LAN2_MDI3P
9	LAN2_MDI3N	10	LAN2_MDI0N
11	LAN2_MDI0P	12	NC
13	VPORT_POS_ALT_A	14	VPORT_NEG_ALT_A
15	NC	16	NC
L1	LAN2_LINK1G#	L2	LAN2_LINK100#
L3	LAN2_LED_ACT#	L4	LAN2_ACT_P

Internal Connectors

DC-in Connector

Connector type: 2x2 Aux power connector
Connector location: JDC1



Pin	Definition
1	GND
2	GND
3	+24V
4	+24V

Power Connector

Connector type: 1x2 2-pin header, 2.0mm pitch
Connector location: JP1



Pin	Definition
1	PWRBTN#_C
2	GND

Reset Connector


Connector type: 1x2 2-pin header, 2.0mm pitch
Connector location: JP2



Pin	Definition
1	RESET
2	GND

BIOS Programming (for debugging only)


Connector type: 2x3 6-pin header, 2.0mm pitch
Connector location: JFW1



Pin	Definition	Pin	Definition
1	3.3V	2	GND
3	SPI_CS#	4	SPI_CK
5	SPI_SO	6	SPI_SI

PoE Connector


Connector type: 1x5 5-pin header, 2.5mm pitch
Connector location: JP3



Pin	Definition	Pin	Definition
1	VIN_M	2	GND
3	NC	4	VPORT_POS_ALT_A
5	VPORT_NEG_ALT_A		

Internal LAN3 Port

Connector type: RJ45 port with LEDs
Connector location: LAN3



Act	Status
Flashing Yellow	Data activity
Off	No activity


Link	Status
Steady Green	1G network link
Steady Orange	100Mbps network link
Off	10Mbps or no link

Pin	Definition	Pin	Definition
1	LAN3_MDI0P	2	LAN3_MDI0N
3	LAN3_MDI1P	4	LAN3_MDI1N
5	LAN3_VCC	6	LAN3TCTG
7	LAN3_MDI2P	8	LAN3_MDI2N
9	LAN3_MDI3P	10	LAN3_MDI3N
11	LAN3_LINK1G#_LED	12	LAN3_LINK
13	LAN3_ACT#_LED	14	LAN3_ACTPW

Internal LAN4 Port

Connector type: RJ45 port with LEDs

Connector location: LAN4



Act	Status
Flashing Yellow	Data activity
Off	No activity


Link	Status
Steady Green	1G network link
Steady Orange	100Mbps network link
Off	10Mbps or no link

Pin	Definition	Pin	Definition
1	LAN4_MDI0P	2	LAN4_MDI0N
3	LAN4_MDI1P	4	LAN4_MDI1N
5	LAN4_VCC	6	LAN4TCTG
7	LAN4_MDI2P	8	LAN4_MDI2N
9	LAN4_MDI3P	10	LAN4_MDI3N
11	LAN4_LINK1G#	12	LAN4_LINK100#_P
13	LAN4_LED_ACT#	14	LAN4_ACT_P

Internal USB 2.0 Connector

Connector type: 1x4 4-pin header, 1.25mm pitch


Connector location: USB1



Pin	Definition	Pin	Definition
1	P5V_USB_P9_P4	2	USB2N9_C
3	USB2P9_C	4	GND

Internal USB 2.0 Connector


Connector type: 1x4 4-pin header, 1.25mm pitch
Connector location: USB2



Pin	Definition	Pin	Definition
1	P5V_USB_P9_P4	2	USB2N4_C
3	USB2P4_C	4	GND

SATA Connector

Connector type: Standard Serial ATA 7P (1.27mm, SATA-M-180)
Connector location: JSATA1



Pin	Definition	Pin	Definition
1	GND	2	SATA_TXP1_C
3	SATA_TXN1_C	4	GND
5	SATA_RXN1_C	6	SATA_RXP1_C
7	GND		

SATA Power Connector


Connector type: 1x4 4-pin header, 1.25mm pitch
Connector location: JSP1



Pin	Definition	Pin	Definition
1	VCC12	2	GND
3	GND	4	VCC5

RS232/RS422/RS485 Serial Port Box Header

Connector type: 2x5 10-pin header, 2.0mm pitch
Connector location: COM2



Pin	Definition	Pin	Definition
1	COM_DCD#2	2	COM_RXD#2
3	COM_TXD#2	4	COM_DTR#2
5	COM_GND	6	COM_DSR#2
7	COM_RTS#2	8	COM_CTS#2
9	COM_RI#2		

RTC Battery Connector

Connector type: 1x2 JST, 2-pin header, 1.25mm pitch
Connector location: JBAT1



Pin	Definition
1	BATT-
2	BATT+

System Fan Connector

Connector type: 1x4 4-pin header, 2.54mm pitch
Connector location: JFAN1



Pin	Definition	Pin	Definition
1	GND	2	FAN2_12V_C
3	FAN_TAC2_C	4	FAN_CTL2_C

CPU Fan Connector


Connector type: 1x4 4-pin header, 2.54mm pitch
Connector location: JFAN2



Pin	Definition	Pin	Definition
1	GND	2	FAN1_12V_C
3	FAN_TAC1_C	4	FAN_CTL1_C

VGA Connector


Connector type: 2x10 20-pin header, 1.25mm pitch
Connector location: VGA1



Pin	Definition	Pin	Definition
1	GND	2	RED_VGA
3	GND	4	GREEN_VGA
5	GND	6	BLUE_VGA
7	NC	8	GND
9	NC	10	VSYNC_VGA
11	GND	12	HSYNC_VGA
13	VGA_SCL_C	14	GND
15	VGA_SDA_C	16	GND
17	GND	18	NC
19	NC	20	VGA_+5V

GPIO Connector


Connector type: 2x10 20-pin header, 2.0mm pitch
Connector location: CN4



Pin	Definition	Pin	Definition
1	GPIO_I0	2	GPIO_I8
3	GPIO_I1	4	GPIO_I9
5	GPIO_I2	6	GPIO_I10
7	GPIO_I3	8	GPIO_I11
9	GPIO_I4	10	GPIO_O0
11	GPIO_I5	12	GPIO_O1
13	GPIO_I6	14	GPIO_O2
15	GPIO_I7	16	GPIO_O3
17	GPIO_GND	18	GPIO_GND
19	VCC5_GPIO	20	VCC5_GPIO

Mini-PCIe Connector

Connector location: JMINI1



Pin	Definition	Pin	Definition
1	WAKE0#	2	+V3.3_MINI2
3	NC	4	GND
5	NC	6	+1V5_MINI2
7	PCIE_CLKREQ6#	8	NC
9	GND	10	NC
11	CLK_PCIE_MINI_N	12	NC
13	CLK_PCIE_MINI_P	14	NC
15	GND	16	NC
17	NC	18	GND
19	NC	20	W_DISABLE#
21	GND	22	PCIE_RST#
23	PCIE_RN6_MINI_C	24	3VSB_MINI2
25	PCIE_RP6_MINI_C	26	GND

Pin	Definition	Pin	Definition
27	GND	28	1V5_MINI2
29	GND	30	SMB_CLK
31	PCIE_TN6_MINI_C	32	SMB_DAT
33	PCIE_TP6_MINI_C	34	GND
35	GND	36	USB2N10_C
37	GND	38	USB2P10_C
39	3VSB_MINI2	40	GND
41	3VSB_MINI2	42	NC
43	GND	44	NC
45	CL_CLK_C	46	NC
47	CL_DAT_C	48	1V5_MINI2
49	CL_RST#_C	50	GND
51	PCIE_mSATA_SEL	52	3VSB_MINI2

PCIe x16 Slot

Connector location: JPCIE1



Pin	Definition	Pin	Definition
A1	PCIE_PRSENT1	B1	12V
A2	12V	B2	12V
A3	12V	B3	12V
A4	GND	B4	GND
A5	TCK	B5	SMB_CLK
A6	TDI	B6	SMB_DATA
A7	NC	B7	GND
A8	TMS	B8	3.3V
A9	3.3V	B9	GND
A10	3.3V	B10	3.3V standby
A11	RESET#	B11	Wake#
A12	GND	B12	NC
A13	CLK+	B13	GND
A14	CLK-	B14	PET0+
A15	GND	B15	PET0-
A16	PER0+	B16	GND
A17	PER0-	B17	PCIECLKRQ8#
A18	GND	B18	GND

Pin	Definition	Pin	Definition
A19	NC	B19	PET1+
A20	GND	B20	PET1-
A21	PER1+	B21	GND
A22	PER1-	B22	GND
A23	GND	B23	PET2+
A24	GND	B24	PET2-
A25	PER2+	B25	GND
A26	PER2-	B26	GND
A27	GND	B27	PET3+
A28	GND	B28	PET3-
A29	PER3+	B29	GND
A30	PER3-	B30	NC
A31	GND	B31	NC
A32	NC	B32	GND
A33	NC	B33	PET4+
A34	GND	B34	PET4-
A35	PER4+	B35	GND
A36	PER4-	B36	GND

Pin	Definition	Pin	Definition
A37	GND	B37	PET5+
A38	GND	B38	PET5-
A39	PER5+	B39	GND
A40	PER5-	B40	GND
A41	GND	B41	PET6+
A42	GND	B42	PET6-
A43	PER6+	B43	GND
A44	PER6-	B44	GND
A45	GND	B45	PET7+
A46	GND	B46	PET7-
A47	PER7+	B47	GND
A48	PER7-	B48	NC
A49	GND	B49	GND
A50	NC	B50	PET8+
A51	GND	B51	PET8-
A52	PER8+	B52	GND
A53	PER8-	B53	GND
A54	GND	B54	PET9+
A55	GND	B55	PET9-
A56	PER9+	B56	GND
A57	PER9-	B57	GND
A58	GND	B58	PET10+
A59	GND	B59	PET10-

Pin	Definition	Pin	Definition
A60	PER10+	B60	GND
A61	PER10-	B61	GND
A62	GND	B62	PET11+
A63	GND	B63	PET11-
A64	PER11+	B64	GND
A65	PER11-	B65	GND
A66	GND	B66	PET12+
A67	GND	B67	PET12-
A68	PER12+	B68	GND
A69	PER12-	B69	GND
A70	GND	B70	PET13+
A71	GND	B71	PET13-
A72	PER13+	B72	GND
A73	PER13-	B73	GND
A74	GND	B74	PET14+
A75	GND	B75	PET14-
A76	PER14+	B76	GND
A77	PER14-	B77	GND
A78	GND	B78	PET15+
A79	GND	B79	PET15-
A80	PER15+	B80	GND
A81	PER15-	B81	NC
A82	GND	B82	NC



CHAPTER 3: BIOS SETUP

This chapter describes how to use the BIOS setup program for RCB 100. The BIOS screens provided in this chapter are for reference only and may change if the BIOS is updated in the future.

To check for the latest updates and revisions, visit the NexCOBOT website at www.nexcobot.com.

About BIOS Setup

The BIOS (Basic Input and Output System) Setup program is a menu driven utility that enables you to make changes to the system configuration and tailor your system to suit your individual work needs. It is a ROM-based configuration utility that displays the system's configuration status and provides you with a tool to set system parameters.

These parameters are stored in non-volatile battery-backed-up CMOS RAM that saves this information even when the power is turned off. When the system is turned back on, the system is configured with the values found in CMOS.

With easy-to-use pull down menus, you can configure such items as:

- Hard drives, diskette drives, and peripherals
- Video display type and display options
- Password protection from unauthorized use
- Power management features

The settings made in the setup program affect how the computer performs. It is important, therefore, first to try to understand all the setup options, and second, to make settings appropriate for the way you use the computer.

When to Configure the BIOS

- This program should be executed under the following conditions:
- When changing the system configuration
- When a configuration error is detected by the system and you are prompted to make changes to the setup program
- When resetting the system clock
- When redefining the communication ports to prevent any conflicts
- When making changes to the Power Management configuration
- When changing the password or making other changes to the security setup

Normally, CMOS setup is needed when the system hardware is not consistent with the information contained in the CMOS RAM, whenever the CMOS RAM has lost power, or the system features need to be changed.

Default Configuration

Most of the configuration settings are either predefined according to the Load Optimal Defaults settings which are stored in the BIOS or are automatically detected and configured without requiring any actions. There are a few settings that you may need to change depending on your system configuration.

Entering Setup














When the system is powered on, the BIOS will enter the Power-On Self Test (POST) routines. These routines perform various diagnostic checks; if an error is encountered, the error will be reported in one of two different ways:

- If the error occurs before the display device is initialized, a series of beeps will be transmitted.
- If the error occurs after the display device is initialized, the screen will display the error message.

Powering on the computer and immediately pressing allows you to enter Setup.

Press the  key to enter Setup:

Legends


Key	Function
 	Moves the highlight left or right to select a menu.
 	Moves the highlight up or down between sub-menus or fields.
	Exits the BIOS Setup Utility.
	Scrolls forward through the values or options of the highlighted field.
	Scrolls backward through the values or options of the highlighted field.
	Selects a field.
	Displays General Help.
	Load previous values.
	Load optimized default values.
	Saves and exits the Setup program.
	Press <Enter> to enter the highlighted sub-menu




Scroll Bar

When a scroll bar appears to the right of the setup screen, it indicates that there are more available fields not shown on the screen. Use the up and down arrow keys to scroll through all the available fields.

Submenu



When “▶” appears on the left of a particular field, it indicates that a submenu which contains additional options are available for that field. To display the submenu, move the highlight to that field and press  .

BIOS Setup Utility

Once you enter the AMI BIOS Setup Utility, the Main Menu will appear on the screen. The main menu allows you to select from several setup functions and one exit. Use arrow keys to select among the items and press  to accept or enter the submenu.

Main

The Main menu is the first screen that you will see when you enter the BIOS Setup Utility.



System Language

Selects the language of the system.

System Date

The date format is <day>, <month>, <date>, <year>. Day displays a day, from Monday to Sunday. Month displays the month, from January to December. Date displays the date, from 1 to 31. Year displays the year, from 1999 to 2099.

System Time

The time format is <hour>, <minute>, <second>. The time is based on the 24-hour military-time clock. For example, 1 p.m. is 13:00:00. Hour displays hours from 00 to 23. Minute displays minutes from 00 to 59. Second displays seconds from 00 to 59.

Advanced

The Advanced menu allows you to configure your system for basic operation. Some entries are defaults required by the system board, while others, if enabled, will improve the performance of your system or let you set some features according to your preference.




Setting incorrect field values may cause the system to malfunction.



CPU Configuration

This section is used to configure the CPU.



Intel® (VMX) Virtualization Technology

Enables or disables Intel Virtualization technology.

Active Processors Cores

Select the number of cores to enable in each processor package.

Hyper-Threading

Enables or disables hyper-threading technology.

Power & Performance

This section is used to configure the CPU power management features.



CPU - Power Management Control

Enters the CPU - Power Management Control submenu.

CPU - Power Management Control



Intel® SpeedStep™


Enables or disables Intel SpeedStep technology.

C states

Enables or disables CPU C states support for power saving.

IT8786 Super IO Configuration

This section is used to configure the I/O functions supported by the onboard Super I/O chip.




Super IO Chip

Displays the Super I/O chip used on the board.

Serial Port 1 Configuration

This section is used to configure serial port 1.



Serial Port

Enables or disables the serial port.

Onboard Serial Port Mode


Select this to change the serial port mode to RS232, RS422, RS485 or RS485 AUTO.

Terminal resistor

Enables or disables the terminal resistor.

Serial Port 2 Configuration

This section is used to configure serial port 2.



Serial Port

Enables or disables the serial port.

Onboard Serial Port Mode


Select this to change the serial port mode to RS232, RS422, RS485 or RS485 AUTO.

Terminal resistor

Enables or disables the terminal resistor.

Hardware Monitor

This section is used to monitor hardware status such as temperature, fan speed and voltages.



FAN Setting

Configures the operating mode of the fan.

Set Temp.-active S.F.

Configures the temperature threshold to activate smart fan.

Set Temp.-active full run

Configures the temperature threshold to activate the fan in full speed.

Initial FAN Speed (S.F.)

Configures the starting fan speed of smart fan.

System Temperature

Detects and displays the current system temperature.

CPU Temperature

Detects and displays the current CPU temperature.

CPU FAN SPEED

Detects and displays the current CPU fan speed.

SYSTEM FAN SPEED

Detects and displays the current system fan speed.

CPU:Vcore

Detects and displays the Vcore voltage.

+3V

Detects and displays the 3.3V voltage.

+12V

Detects and displays the 12V voltage.

+5V

Detects and displays the 5V voltage.

CSM Configuration

This section is used to configure the compatibility support module features.



CSM Support

This field is used to enable or disable CSM support, if Auto option is selected, based on OS, CSM will be enabled or disabled automatically.

GateA20 Active

Upon Request GA20 can be disabled using BIOS services.
Always Do not allow disabling GA20; this option is useful when any RT code is executed above 1MB.

Option ROM Messages

This field is used to set display mode for Option ROM. The options are Force BIOS and Keep Current.

INT19 Trap Response

Allows Option ROMs to trap Interrupt 19 when enabled.

Immediate	Execute the trap right away.
Postponed	Execute the trap during legacy boot.

Boot option filter

Configures which devices the system will boot from.

Storage

Controls the execution of UEFI and Legacy Storage OpROM.

Video

Controls the execution of UEFI and Legacy Video OpROM.

Other PCI Devices

Configures the OpROM execution policy for devices other than Storage or Video.

USB Configuration

This section is used to configure the USB.

Aptio Setup Utility - Copyright (C) 2018 American Megatrends, Inc.

Advanced

USB Configuration		Enables Legacy USB support. AUTO option disables legacy support if no USB devices are connected. DISABLE option will keep USB devices available only for EFI applications.
USB Module Version	17	
USB Controllers: 1 XHCI		
USB Devices: 1 Keyboard, 1 Mouse		
Legacy USB Support	[Enabled]	
XHCI Hand-off	[Enabled]	
USB hardware delays and time-outs:		
Device reset time-out	[20 sec]	←→: Select Screen ↑↓: Select Item Enter: Select +/-: Change Opt. F1: General Help F2: Previous Values F3: Optimized Defaults F4: Save & Exit ESC: Exit

Version 2.18.1263, Copyright (C) 2018 American Megatrends, Inc.

Legacy USB Support

Enabled Enables Legacy USB.
 Auto Disables support for Legacy when no USB devices are connected.
 Disabled Keeps USB devices available only for EFI applications.

XHCI Hand-off

This is a workaround for OSs that does not support XHCI hand-off. The XHCI ownership change should be claimed by the XHCI driver.

Device reset time-out

Selects the USB mass storage device's start unit command timeout.

Chipset

This section gives you functions to configure the system based on the specific features of the chipset. The chipset manages bus speeds and access to system memory resources.



Setting incorrect field values may cause the system to malfunction.

System Agent (SA) Configuration

This section is used to configure the System Agent (SA) configuration.



VT-d

Enables or disables VT-d function on MCH.

Graphics Configuration




Primary Display

Selects which IGFX/PEG/PCI graphics device should be the primary display.

DVMT Total Gfx Mem

Configures the DVMT 5.0 total graphic memory size used by the IGD.

PEG Port Configuration




Enable Root Port

Enables or disables the root port.

Max Link Speed

Select the maximum link speed of the PEG device.

PCH-IO Configuration



State After G3

Configures the state the system will enter when power is reapplied after a power failure (G3 state).

CON1

Enables or disables CON1 connector.

LAN2 to LAN4

Enables or disables LAN2 to LAN4 controllers.

Mini-PCIE(JMINI1)

Enables or disables the PCI Express root port for mini-PCle (JMINI1).

SATA And RST Configuration



SATA Controller(s)

Enables or disables SATA device.

SATA Mode Selection

Configures the SATA controller as AHCI mode.

Security Configuration



RTC Lock

Enables or disables bytes 38h-3Fh in the lower and upper 128-byte bank of RTC RAM lockdown.

Security



Administrator Password

Select this to reconfigure the administrator's password.

User Password

Select this to reconfigure the user's password.

Boot



Setup Prompt Timeout

Selects the number of seconds to wait for the setup activation key. 65535(0xFFFF) denotes indefinite waiting.

Bootup NumLock State

This allows you to determine the default state of the numeric keypad. By default, the system boots up with NumLock on wherein the function of the numeric keypad is the number keys. When set to Off, the function of the numeric keypad is the arrow keys

Quiet Boot

Enabled Displays OEM logo instead of the POST messages.
Disabled Displays normal POST messages.

Boot Option Priorities

Adjust the boot sequence of the system. Boot Option #1 is the first boot device that the system will boot from, next will be #2 and so forth.

Fast Boot

Enables or disables boot with initialization of a minimal set of devices required to launch active boot option. Has no effect for BBS boot options.

Save & Exit



Save Changes and Exit

To save the changes and exit the Setup utility, select this field then press <Enter>. A dialog box will appear. Confirm by selecting Yes. You can also press <F4> to save and exit Setup.

Discard Changes and Exit

To exit the Setup utility without saving the changes, select this field then press <Enter>. You may be prompted to confirm again before exiting. You can also press <ESC> to exit without saving the changes.

Save Changes and Reset

To save the changes and reset, select this field then press <Enter>. A dialog box will appear. Confirm by selecting Yes.

Discard Changes and Reset

To exit the Setup utility and reset without saving the changes, select this field then press <Enter>. You may be prompted to confirm again before exiting.

Save Changes

To save changes and continue configuring the BIOS, select this field then press <Enter>. A dialog box will appear. Confirm by selecting Yes.

Discard Changes

To discard the changes, select this field then press <Enter>. A dialog box will appear. Confirm by selecting Yes to discard all changes made and restore the previously saved settings.

Restore Defaults

To restore the BIOS to default settings, select this field then press <Enter>. A dialog box will appear. Confirm by selecting Yes.

Save as User Defaults

To use the current configurations as user default settings for the BIOS, select this field then press <Enter>. A dialog box will appear. Confirm by selecting Yes.

Restore User Defaults

To restore the BIOS to user default settings, select this field then press <Enter>. A dialog box will appear. Confirm by selecting Yes.

Boot Override

To bypass the boot sequence from the Boot Option List and boot from a particular device, select the desired device and press <Enter>.

Launch EFI Shell from filesystem device

To launch EFI shell from a filesystem device, select this field and press <Enter>.